


Selecting Pickups

- 1: Bridge Pickup  
(Blue LED)
- 2: Bridge and Neck Pickups  
(Blue and Green LEDs)
- 3: Neck Pickup  
(Green LED)



**NOTE** Battery is only for lighting. Output is not interrupted if battery runs out.

Adjustment of Bridge

■ String Action

Adjust the bridge saddle height by rotating height adjustment screws ①.

■ Intonation Adjustment

If the pitch at the 12th fret is sharp compared to the harmonic tone:

→ Rotate the intonation adjusting screw ② clockwise.

If the pitch at the 12th fret is flat compared to the harmonic tone:

→ Rotate the intonation adjusting screw ② counter-clockwise.

